


4-Gang Touch Panel

Product Diagrams V 1.2

Model: TER-4G-A










Figure 1: TER-4G-A & ADD-3R-5A Lights Connection Diagram

4-Gang Touch Panel Model: TER-4G-A











Figure 2: TER-4G-A & ADD-3R-5A Motors Connection Diagram



4-Gang Touch Panel Model: TER-4G-A







2.5 mm Electric Cable
1.5 mm Electric Cable
1.5 mm Electric Cable
Cat5e connection

Cat5e connection

D-(white-green)&(white-blue)
D+(blue-green)
+24V(brown-orange)


Figure 3: TER-4G-A & ADD-3R-5A FCU Connection Diagram



4-Gang Touch Panel Model: TER-4G-A







Electric Lock

 $\bigcirc$ 

low voltage cable
low voltage cable
1.5 mm Electric Cable
1.5 mm Electric Cable
Cat5e connection

Cat5e connection

Let Voltage cable

1.5 mm Electric Cable
Childrenge (white-brown)
D-(white-green)&(white-blue)
D+(blue-green)
Let Voltage cable
Le

Figure 4: TER-4G-A& ADD-3R-5A Electric Lock Connection Diagram



Connect To N

Connect To L •

AC/DC ADAPTER

Input 110~220V AC Output 12V DC

4-Gang Touch Panel Model: TER-4G-A












Figure 5: TER-4G-A & ADD-3DL-12V Magnetic Door Contact Connection Diagram



4-Gang Touch Panel Model: TER-4G-A









▲ Figure 6: TER-4G-A & ADD-3DL-12V 3rd Party Sensor Connection Diagram



4-Gang Touch Panel Model: TER-4G-A







▲ Figure 7: TER-4G Connection Diagram



4-Gang Touch Panel Model: TER-4G-A










Figure 8: Module's Dimension Diagram

